Power LED   Signal Led

Walk outside
Wait for Green Signal
LED

Power LED   Signal Led

NEAREST
Push Joystick Down Once

Gipsi reports NEAREST Runway/Airport
  Push Joystick FWD
    GiPSi Reports Next closest Airport
  Push Joystick BACK
    Gipsi Reports Previous closest Airport
  Push Joystick RIGHT
    Gipsi Reports current NEAREST DISTANCE
        (Class Bravo avoidance)
  Push Joystick LEFT
    GiPSi Reports WHERE (Releative to Airport)

Power LED   Signal Led

WAYPOINT
Push Joystick Down Twice

Gipsi reports First WAYPOINT (You have stored)
  Push Joystick FWD
    GiPSi Reports Next WAYPOINT
  Push Joystick BACK
    Gipsi Reports Previous WAYPOINT
  Push Joystick RIGHT
    Gipsi Reports PANEL Instruments
  Push Joystick LEFT
    GiPSi Reports WHERE

Power LED   Signal Led

LOGPOINTS
Push Joystick Down Three
times

Gipsi reports First Stored LOGPOINT
  Push Joystick FWD
    GiPSi Reports Next LOGPOINT
  Push Joystick BACK
    Gipsi Reports Previous LOGPOINT
  Push Joystick RIGHT
    Gipsi Reports PANEL Instruments
  Push Joystick LEFT
    GiPSi Reports WHERE

For further detail on any command please see Command Schematic and the User Manual